

# Care In Use



## TEA INFUSER

**Churchill's stainless steel tea filter is designed to work with specific ceramic beverage pots, the fine mesh finish creates the ideal, leaf free infusion.**

Made with top quality 18/10 stainless steel, the infuser is dishwasher safe and designed to meet the demands of a busy hospitality environment. Handling with care and following the guidelines below will help to prolong the life of your product.

### USES

- ☒ Hand washing is recommended. If using a dishwasher, follow manufacturers instructions. Dishwasher Settings, use of salt and water softener should be appropriate for water hardness in your area.
- ☒ Rinse filter immediately after use to remove tea leaves, then wash as soon as possible after use.
- ☒ Remove and dry immediately after the end of the dishwasher programme (avoid rinse and hold programmes as soaking can be damaging).
- ☒ Store in a dry environment.
- ☒ Use in suitable Teapot.

### MISUSES

- ☒ Do not leave to soak.
- ☒ Do not use hard or improper detergents or corrosive liquids, such as bleach or vinegar.
- ☒ Sometimes leaves become bound in the filter, do not use hard brushes, such as cleaning wire to remove.
- ☒ Water marks and food residues can be indicative of improper care and use.
- ☒ Not suitable for use in oven or microwave.



Food Safe



Dishwasher  
Safe



Packaging is  
fully recyclable